

MODEL #

| | | | | | | | | | | |
|------------|---------|----------|----------|----------|----------|--------|--------|---------|----------|----------|
| 691-4 VT2 | 1 | 1 | 1 | 2 | 2 | 2 | 3 | 3 | 4 | 12t |
| | 4 | 8-3/8 | 13-5/8 | 19-11/16 | 27-11/16 | 36-1/8 | 45-1/8 | 54-5/8 | 65-15/16 | 76-13/16 |
| 696-4 VT2 | 1 | 1 | 1 | 1 | 2 | 2 | 2 | 3 | 3 | 4 |
| | 4-15/16 | 9-7/8 | 15-5/8 | 22-3/16 | 29-1/4 | 37-1/8 | 44-3/4 | 52-5/8 | 61-7/8 | 72-5/16 |
| 697-4 VT2 | 1 | 1 | 1 | 1 | 2 | 2 | 2 | 3 | 3 | 4 |
| | 4-15/16 | 9-7/8 | 15-5/8 | 22-3/16 | 29-1/4 | 37-1/8 | 44-3/4 | 52-5/8 | 61-7/8 | 72-5/16 |
| 790-4 VT2 | 1 | 1 | 2 | 2 | 3 | 3 | 4 | 4 | 10t | 12t |
| | 4 | 8-3/8 | 13-5/8 | 19-11/16 | 27-11/16 | 36-1/8 | 45-1/8 | 54-5/8 | 65-15/16 | 76-13/16 |
| 796-4 VT2 | 1 | 1 | 1 | 2 | 2 | 2 | 2 | 3 | 4 | 12t |
| | 4-15/16 | 9-7/8 | 15-5/8 | 22-3/16 | 29-1/4 | 37-1/8 | 44-3/4 | 52-5/8 | 61-7/8 | 72-5/16 |
| 890-4 VT2 | 1 | 1 | 2 | 2 | 3 | 3 | 4 | 5 | 12t | 16t |
| | 4 | 8-3/8 | 13-5/8 | 19-11/16 | 27-11/16 | 36-1/8 | 45-1/8 | 54-5/8 | 65-15/16 | 76-13/16 |
| 896-4 VT2 | 1 | 1 | 1 | 2 | 2 | 2 | 2 | 3 | 4 | 12t |
| | 4-15/16 | 9-7/8 | 15-5/8 | 22-3/16 | 29-1/4 | 37-1/8 | 44-3/4 | 52-5/8 | 61-7/8 | 72-5/16 |
| 990-4 VT2 | 1 | 1 | 2 | 2 | 3 | 3 | 4 | 5 | 12t | 16t |
| | 4 | 8-3/8 | 13-5/8 | 19-11/16 | 27-11/16 | 36-1/8 | 45-1/8 | 54-5/8 | 65-15/16 | 76-13/16 |
| 1090-4 VT2 | 2 | 2 | 3 | 3 | 3 | 3 | 4 | 5 | 12t | 16t |
| | 4 | 8-3/8 | 13-5/8 | 19-11/16 | 27-11/16 | 36-1/8 | 45-1/8 | 54-5/8 | 65-15/16 | 76-13/16 |
| 286 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1 | 2 | 3 | 10t | |
| | 5-1/16 | 11-11/16 | 17-3/4 | 25-3/4 | 33-3/4 | 42-5/8 | 51-1/2 | 60-3/4 | 71-3/8 | |
| 380 XP | 1/0t | 1/0t | 1/0t | 1t | 1 | 1 | 2 | 3 | 10t | |
| | 4-11/16 | 9-15/16 | 15-13/16 | 22-3/4 | 30-7/8 | 39-1/8 | 48-1/8 | 57-9/16 | 67-1/8 | |
| 390 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1t | 1 | 2 | 4 | 12t |
| | 5 | 10-1/8 | 16-1/8 | 22-1/4 | 29-1/2 | 37-1/8 | 45-3/8 | 54-1/4 | 65-3/16 | 77-3/8 |
| 476 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1 | 2 | 3 | 10t | |
| | 4-3/4 | 9-1/8 | 14-1/2 | 21-1/6 | 28-11/16 | 36-1/8 | 45-3/8 | 53-3/8 | 62-3/4 | |

MODEL #

| | | | | | | | | | |
|---------------|---------|----------|----------|----------|---------|--------|---------|----------|---------|
| 486 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1 | 2 | 3 | 10t |
| | 5-1/16 | 11-11/16 | 17-3/4 | 25-3/4 | 33-3/4 | 42-5/8 | 51-1/2 | 60-3/4 | 71-3/8 |
| 490 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1t | 1 | 2 | 4 |
| | 5 | 10-1/8 | 16-1/8 | 22-1/4 | 29-1/2 | 37-1/8 | 45-3/8 | 54-1/4 | 65-3/16 |
| 580 XP | 1/0t | 1/0t | 1/0t | 1t | 1 | 2 | 3 | 4 | 12t |
| | 4-11/16 | 9-15/16 | 15-13/16 | 22-3/4 | 30-7/8 | 39-1/8 | 48-1/8 | 57-9/16 | 67-1/8 |
| 586 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1 | 2 | 3 | 12t |
| | 5-1/16 | 11-1/16 | 17-3/4 | 25-3/4 | 33-3/4 | 42-5/8 | 51-1/2 | 60-4/3 | 71-3/8 |
| 590 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1t | 1 | 2 | 4 |
| | 5 | 10-1/8 | 16-1/8 | 22-1/4 | 29-1/2 | 37-1/8 | 45-3/8 | 54-1/4 | 65-3/16 |
| 596 XP | 1t | 1t | 1t | 1t | 1 | 1 | 2 | 3 | 4 |
| | 4-7/8 | 9-11/16 | 15-9/16 | 21-11/16 | 28-7/16 | 35-1/2 | 43-3/16 | 51-15/16 | 61-1/4 |
| 690 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1t | 1 | 2 | 4 |
| | 5 | 10-1/8 | 16-1/8 | 22-1/4 | 29-1/2 | 37-1/8 | 45-3/8 | 54-1/4 | 65-3/16 |
| 696 XP | 1t | 1t | 1t | 1t | 1 | 1 | 2 | 3 | 4 |
| | 4-7/8 | 9-11/16 | 15-9/16 | 21-11/16 | 28-7/16 | 35-1/2 | 43-3/16 | 51-15/16 | 61-1/4 |
| 790 XP | 1 | 1 | 1 | 2 | 2 | 2 | 3 | 4 | 12t |
| | 5 | 10-1/8 | 16-1/8 | 22-1/4 | 29-1/2 | 37-1/8 | 45-3/8 | 54-1/4 | 65-3/16 |
| 796 XP | 1 | 1 | 1 | 2 | 2 | 2 | 2 | 3 | 4 |
| | 4-7/8 | 9-11/16 | 15-9/16 | 21-11/16 | 28-7/16 | 35-1/2 | 43-3/16 | 51-15/16 | 61-1/4 |
| 890 XP | 1 | 1 | 1 | 2 | 2 | 2 | 3 | 4 | 12t |
| | 5 | 10-3/8 | 16-1/8 | 22-1/4 | 29-1/2 | 37-1/8 | 45-3/8 | 54-1/4 | 65-3/16 |
| 896 XP | 1 | 1 | 1 | 2 | 2 | 2 | 2 | 3 | 4 |
| | 4-7/8 | 9-11/16 | 15-9/16 | 21-11/16 | 28-7/16 | 35-1/2 | 43-3/16 | 51-15/16 | 61-1/4 |
| 990 XP | 2 | 2 | 2 | 2 | 2 | 2 | 3 | 4 | 12t |
| | 5 | 10-1/8 | 16-1/8 | 22-1/4 | 29-1/2 | 37-1/8 | 45-3/8 | 54-1/4 | 65-3/16 |

MODEL #

| | | | | | | | | | | | |
|------------------|---------|----------|--------|----------|----------|--------|---------|---------|----------|---------|--------|
| 1090 XP | 2 | 2 | 2 | 2 | 2 | 3 | 4 | 12t | 16t | | |
| | 5 | 10-1/8 | 16-1/8 | 22-1/4 | 29-1/2 | 37-1/8 | 45-3/8 | 54-1/4 | 65-3/16 | 77-3/8 | |
| 386-4 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1 | 2 | 3 | 10t | | |
| | 4-3/4 | 10-11/16 | 17-1/2 | 25-9/16 | 33-15/16 | 42-1/2 | 51-9/16 | 61-1/16 | 72-1/4 | | |
| 486-4 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1 | 2 | 3 | 10t | | |
| | 4-3/4 | 10-11/16 | 17-1/2 | 25-9/16 | 33-15/16 | 42-1/2 | 51-9/16 | 61-1/16 | 72-1/4 | | |
| 490-4 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1t | 1 | 2 | 4 | 12t | |
| | 4 | 8-3/8 | 13-5/8 | 19-11/16 | 27-11/16 | 36-1/8 | 45-1/8 | 54-5/8 | 65-15/16 | 77-1/2 | |
| 4100-4 XP | 1t | 1t | 1t | 1t | 1 | 1 | 2 | 2 | 3 | 4 | 12t |
| | 6 | 12-1/16 | 18-1/4 | 24-5/16 | 30-5/8 | 38-1/8 | 46-7/8 | 56-1/4 | 65-13/16 | 76 | 87-1/2 |
| 586-4 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1 | 2 | 3 | 12t | | |
| | 4-3/4 | 10-11/16 | 17-1/2 | 25-9/16 | 33-15/16 | 42-1/2 | 51-9/16 | 61-1/16 | 72-1/4 | | |
| 590-4 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1t | 1 | 2 | 4 | 12t | |
| | 4 | 8-3/8 | 13-5/8 | 19-11/16 | 27-11/16 | 36-1/8 | 45-1/8 | 54-5/8 | 65-15/16 | 77-1/2 | |
| 596-4 XP | 1t | 1t | 1t | 1t | 1 | 1 | 2 | 2 | 3 | 4 | 12t |
| | 4-15/16 | 9-7/8 | 15-5/8 | 22-3/16 | 29-1/4 | 37-1/8 | 44-3/4 | 52-5/8 | 61-7/8 | 72-5/16 | 85-1/4 |
| 5100-4 XP | 1t | 1t | 1t | 1t | 1 | 1 | 2 | 2 | 3 | 4 | 12t |
| | 6 | 12-1/16 | 18-1/4 | 24-5/16 | 30-5/8 | 38-1/8 | 46-7/8 | 56-1/4 | 65-13/16 | 76 | 87-1/2 |
| 690-4 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1t | 1 | 2 | 4 | 12t | |
| | 4 | 8-3/8 | 13-5/8 | 19-11/16 | 27-11/16 | 36-1/8 | 45-1/8 | 54-5/8 | 65-15/16 | 77-1/2 | |
| 691-4 XP | 1/0t | 1/0t | 1/0t | 1/0t | 1t | 1t | 1 | 2 | 4 | 12t | |
| | 4 | 8-3/8 | 13-5/8 | 19-11/16 | 27-11/16 | 36-1/8 | 45-1/8 | 54-5/8 | 65-15/16 | 77-1/2 | |
| 696-4 XP | 1t | 1t | 1t | 1t | 1 | 1 | 2 | 2 | 3 | 4 | 12t |
| | 4-15/16 | 9-7/8 | 15-5/8 | 22-3/16 | 29-1/4 | 37-1/8 | 44-3/4 | 52-5/8 | 61-7/8 | 72-5/16 | 85-1/4 |
| 697-4 XP | 1t | 1t | 1t | 1t | 1 | 1 | 2 | 2 | 3 | 4 | 12t |
| | 4-15/16 | 9-7/8 | 15-5/8 | 22-3/16 | 29-1/4 | 37-1/8 | 44-3/4 | 52-5/8 | 61-7/8 | 72-5/16 | 85-1/4 |

MODEL #

| | | | | | | | | | | | |
|------------------|---------|---------|---------|----------|----------|--------|--------|--------|----------|---------|---------|
| 6100-4 XP | 1t | 1t | 1t | 1t | 1 | 1 | 2 | 2 | 3 | 4 | 12t |
| | 6 | 12-1/16 | 18-1/4 | 24-5/16 | 30-5/8 | 38-1/8 | 46-7/8 | 56-1/4 | 65-13/16 | 76 | 87-1/2 |
| 6101-4 XP | 1t | 1t | 1t | 1t | 1 | 1 | 2 | 2 | 3 | 4 | 12t |
| | 6 | 12-1/16 | 18-1/4 | 24-5/16 | 30-5/8 | 38-1/8 | 46-7/8 | 56-1/4 | 65-13/16 | 76 | 87-1/2 |
| 6110-4 XP | 1 | 1 | 1 | 2 | 2 | 2 | 3 | 4 | 12t | 16t | |
| | 7 | 14-3/16 | 22-1/16 | 31-11/16 | 41-11/16 | 52-1/2 | 64-3/8 | 76-5/8 | 89-1/4 | 103-1/8 | |
| 790-4 XP | 1 | 1 | 1 | 2 | 2 | 2 | 3 | 4 | 12t | 16t | |
| | 4 | 8-3/8 | 13-5/8 | 19-11/16 | 27-11/16 | 36-1/8 | 45-1/8 | 54-5/8 | 65-15/16 | 77-1/2 | |
| 796-4 XP | 1 | 1 | 1 | 2 | 2 | 2 | 2 | 3 | 4 | 12t | 16t |
| | 4-15/16 | 9-7/8 | 15-5/8 | 22-3/16 | 29-1/4 | 37-1/8 | 44-3/4 | 52-5/8 | 61-7/8 | 72-5/16 | 85-1/4 |
| 7100-4 XP | 1 | 1 | 1 | 1 | 2 | 2 | 3 | 4 | 5 | 12t | 16t |
| | 6 | 12-1/16 | 18-1/4 | 24-5/16 | 30-5/8 | 38-1/8 | 46-7/8 | 56-1/4 | 65-13/16 | 76 | 87-1/2 |
| 890-4 XP | 1 | 1 | 1 | 2 | 2 | 2 | 3 | 4 | 12t | 16t | |
| | 4 | 8-3/8 | 13-5/8 | 19-11/16 | 27-11/16 | 36-1/8 | 45-1/8 | 54-5/8 | 65-15/16 | 77-1/2 | |
| 896-4 XP | 1 | 1 | 1 | 2 | 2 | 2 | 2 | 3 | 4 | 12t | 16t |
| | 4-15/16 | 9-7/8 | 15-5/8 | 22-3/16 | 29-1/4 | 37-1/8 | 44-3/4 | 52-5/8 | 61-7/8 | 72-5/16 | 85-1/4 |
| 8100-4 XP | 1 | 1 | 1 | 1 | 2 | 2 | 3 | 4 | 5 | 12t | 16t |
| | 6 | 12-1/8 | 18-1/4 | 24-3/8 | 30-11/16 | 38-1/4 | 46-7/8 | 56-1/4 | 65-7/8 | 76 | 87-7/16 |
| 990-4 XP | 2 | 2 | 2 | 2 | 2 | 2 | 3 | 4 | 12t | 16t | |
| | 4 | 8-3/8 | 13-5/8 | 19-11/16 | 27-11/16 | 36-1/8 | 45-1/8 | 54-5/8 | 65-15/16 | 77-1/2 | |
| 996-4 XP | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 3 | 4 | 12t | 16t |
| | 4-15/16 | 9-7/8 | 15-5/8 | 22-3/16 | 29-1/4 | 37-1/8 | 44-3/4 | 52-5/8 | 61-7/8 | 72-5/16 | 85-1/4 |
| 9100-4 XP | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 3 | 4 | 12t | 16t |
| | 6 | 12-1/16 | 18-1/4 | 24-5/16 | 30-5/8 | 38-1/8 | 46-7/8 | 56-1/4 | 65-13/16 | 76 | 87-1/2 |
| 1090-4 XP | 2 | 2 | 2 | 2 | 2 | 2 | 3 | 4 | 12t | 16t | |
| | 4 | 8-3/8 | 13-5/8 | 19-11/16 | 27-11/16 | 36-1/8 | 45-1/8 | 54-5/8 | 65-15/16 | 77-1/2 | |